



Reservoirs with pump

For your wash system you can use the water from a stand alone reservoir. As soon as the integral pumps receive a signal via the wiper control, it will open and provide water for the wash/wipe program.

Pos	Description	Voltage	Item no.
1	Reservoir 8,0 ltr with 1 pump	12 V	2193
2	Reservoir 8,0 ltr with 3 pumps	12 V	PT0701044
3	Reservoir 8,0 ltr with 3 pumps	24 V	PT0701045
4	Reservoir 1,2 ltr with 1 pump	12 V	2100.PT-0701080
	Reservoir 5,0 ltr with 1 pump	24 V	2100.PT0701021
	Reservoir 20 ltr with 3 pumps	24 V	2192
	Reservoir 1,2 ltr with 1 pump	24 V	2100.PT-0701081
	Reservoir 5,7 ltr with 1 pump	24 V	2100.PT-2752
	Reservoir 8,0 ltr with 1 pump	24 V	2194
	Reservoir 8,0 ltr with 1 pump threaded	24 V	2100.PT-2875
	Reservoir 8,0 ltr with 2 pumps	24 V	2194.10
	Reservoir 8,0 ltr with 2 pumps	12 V	PT0701042
	Reservoir 8,0 ltr with 2 pumps	24 V	PT0701043
	Reservoir 27 ltr with 3 pumps	24 V	2100.zxa163-3
	Connectionset for 2192		2192.2169
	Connectionset for 2193 and 2194		2193.con



Solenoid valves

For your wash system you can use the water from your on board pressure supply. You only need a solenoid valve. As soon as the valve gets a signal via the wiper control, it will open to provide water for the wipe/wash program.

Pos	Description	Voltage	Connections	Item no.
1	Solenoid valve 1/8 12V	12 V	1/8" B.S.P.	2137
-	Solenoid valve 1/8 24V	24 V	1/8" B.S.P.	2138
2	Solenoid valve 1/4 12V	12 V	1/4" B.S.P.	2142
-	Solenoid valve 1/4 24V	24 V	1/4" B.S.P.	2143

